

before pouring any concrete curbs.

measurements are recommended

Laying Pattern Z (Staggered Running Bond)

center of joint) based on a specific joint size. Field layout and