



CURVED WALLS:



CUTTING WILL BE REQUIRED FOR ANY CURVED WALLS. MAKING TWO CUTS ON ONE COPING AND THEN NOT CUTTING THE COPING ON EITHER SIDE PRODUCES THE MOST PLEASING LOOK.


90-DEGREE CORNERS:



FOR 90-DEGREE CORNERS, MITER TWO COPING UNITS AT 45 DEGREES EACH. THIS PROVIDES A SPLIT FACE ON EACH OF THE TWO EXPOSED SIDES.

ELEVATION CHANGES:

USE CORNER UNITS ON EXPOSED ENDS



FOR STEPPED WALLS, ALWAYS START THE COPING FROM THE LOWEST ELEVATION.

GENERAL NOTES: LAY OUT COPING PRIOR TO USING ADHESIVE. USE EXTERIOR-GRADE CONSTRUCTION ADHESIVE TO SECURE COPING. COPING UNITS ARE SUPPLIED WITH A RECESS TO THE BOTTOM OF THE UNIT TO ACCOMMODATE THE LOCATOR AT THE TOP OF THE WALL UNITS; THE COPING SHOULD ALWAYS BE INSTALLED WITH THE RECESS FACING DOWNWARD.



This graphic represents a preliminary, non site-specific design. If used for construction, a registered professional engineer must be retained to review & approve the design, confirm site conditions, and inspect construction.

Ortana Retaining Wall System  
Coping Details